
















Lego EV3
Balance
Unicycle









1x




1x




6x




2x



2x



2x



2x




6x



19x





2x





2x



1







2






3





4






5






6





7






8





9




10



11



12




Non-original LEGO rubber bands



非乐高原装橡皮筋

Because Lego studio software cannot simulate rubber bands This picture is taken from the real thing



由于乐高studio软件无法模拟橡皮筋 此图由实物拍摄





13





14





15





16





17






18





19





20





21






22




23







24






25





26





27




28





29





The wheel is in the middle
轮子在最中间





30




31




32




33




34



35





ФАЙЛЫ С ГОТОВЫМИ ПРОГРАММАМИ МОЖНО СКАЧАТЬ ПО ССЫЛКЕ:

<https://disk.yandex.ru/d/EARrHuK4op3BBw>

A	B 2716	C	D
1	2 0	3	4 0



LEGO education



2 0 4 0 B -488°

```
when program starts
  forever
    2 wait until pressed
    B start motor clockwise
    B set speed to 75 %
    2 wait until released
    B stop motor
```

```
when program starts
  forever
    4 wait until pressed
    B start motor counterclockwise
    B start motor at -75 % power
    4 wait until released
    B stop motor
```